ES5000 Outside Access Fitting Instructions

Part number: PAN95000

1

Description: ES5000 Mechanical outside access keypad

Boxed quantity:

Use the following instructions for ES5000 digital outside access device in conjunction with appropriate exit device fitting instructions.

After establishing correct position of exit mechanism on door face, remove the mechanism for fitting of digital outside access device.

After determining correct hand insert 8mm spindle into handle follower and cam as shown. The devices are supplied with both LH and RH spindles - care should be taken to ensure the spindle is cut down to correct size and the cut end enters the handle follower.

Secure digital outside access device to fixing plate using one of the M4 screws provided into lower fixing post. Ensure cam is free to rotate.

The fixing plate is then secured with appropriate screw for material and then secure other M4 screw to top fixing post through section.

The mechanism can now be positioned onto fixing plate as shown with appropriate screws.





